



ROBOTUNITS®

SYSTEMATICALLY. BETTER. TOGETHER.



COBOT STATION

Operating / Installation Instructions

TABLE OF CONTENTS

1. General information 3

1.1 System manufacturer 3

1.2 Version 3

2. Safety 4

2.1 Intended use 4

3. Technical data 5

3.1 Compatible collaborative robots 5

4. Mechanical design 6

5. Assembly 7

5.1 Mounting a collaborative robot 7

5.2 Cable routing, sensors 9

6. Transportation 10

6.1 Storage/transport conditions 10

7. Commissioning 11

7.1 Personnel requirements 11

7.2 Connection/wiring 11

8. Maintenance, servicing and cleaning 12

9. Disposal 13


1. GENERAL INFORMATION

1.1 SYSTEM MANUFACTURER

Robotunits GmbH
Dr. Walter Zumbobel Str. 2
A-6850 Dornbirn
Tel. +43 5572 22000 200
Fax +43 5572 22000 9200
info.usa1@robotunits.com
www.robotunits.com

1.2 VERSION

Version	Type	Date
01	translation of the original document	2023-08-06



2. SAFETY

2.1 INTENDED USE

The Cobot Station serves as a mobile stand for collaborative robots.

In the sense of the Machinery Directive 2006/42/EC, the Cobot Station is "interchangeable equipment". Declaration of conformity: see appendix.

 WARNING	
 	Death or serious injury due to tipping of the Cobot Station There is a risk of injury if the Cobot Station tips over. ➤ Consider tipping moments. ➤ Fix the substructure to the floor if necessary. ➤ Observe the mounting instructions of the cobot manufacturer.

3. TECHNICAL DATA

3.1 COMPATIBLE COLLABORATIVE ROBOTS

Cobot	Unit	Value
max. reach	[mm]	1400
TCP speed	[mm/s]	500
max. handling weight	[kg]	10
max. dead weight of cobot	[kg]	40
Controls	Recommendation: Installation in the substructure	

Compatible, among others, with the following products:

ABB

CRB 14050 (YuMi)

CRB 15000 (GoFa)

IRB/CRB 1100 (SWIFTI)

Fanuc

CR-4iA

CRX-5iA

CR-7iA and CR-7iA/L

CRX-10iA

CRX-10iA/L

UR

UR3e

UR5e

UR10e

Information: The reach and the handling weight are used to calculate the tipping moment, which is decisive for assessing the risk of tipping.


Substructure

Deviation from the standard dimensions can result in an altered stability .

Substructure	Unit	Value
min. width	[mm]	800
min. length	[mm]	1000
max. top surface height	[mm]	1000
min. weight	[kg]	70

4. MECHANICAL DESIGN

Dimensions:





5. ASSEMBLY

5.1 MOUNTING A COLLABORATIVE ROBOT

 CAUTION	
	Risk of injury if the cobot is too heavy or too large There is a risk of injury if the Cobot Station tips over. ➤ Only mount compatible collaborative robots (see technical data). ➤ Mount the cobot in the center. ➤ Take tipping moments into account and fix the substructure to the floor if necessary. ➤ Observe the mounting instructions of the cobot manufacturer.

NOTICE	
	Material damage due to tipping There is a risk of damaging the cobot if the Cobot Station tips over. ➤ Mounting must be carried out by authorized qualified personnel. ➤ Only mount compatible collaborative robots (see technical data). ➤ Mount the cobot in the center. ➤ Take tipping moments into account and fix the substructure to the floor if necessary. ➤ Observe the mounting instructions of the cobot manufacturer.

The manufacturer recommends the use of adjustable floor brackets (e.g. 4 x BAP2017 or 4 x BAP2051).



5. ASSEMBLY

WARNING




Risk of injury due to tipping over or falling of the cobot

If screws are used that are too short, there is a risk of being pulled out.

- Observe the installation instructions of the cobot manufacturer, in particular the screws specifications.
- Consider using longer screws to utilize the full screw-in depth of the mounting plate.

Example drawing: central mounting position of the cobot



5.2 CABLE ROUTING, SENSORS

The cable routing and sensors are to be handled by the customer. If grounding is required, this must also be handled by the customer. All the connectors are conductive.

6. TRANSPORTATION

6.1 STORAGE/TRANSPORT CONDITIONS

⚠ WARNING	
 	Serious injuries due to tipping of the Cobot Station Incorrect storage or improper transport of the Cobot Station may result in injury to the upper and lower limbs. ➤ Transport only with industrial trucks. Avoid suspended transport. ➤ During transport and storage, secure the station to prevent it from tipping.

NOTICE	
	Material damage due to improper storage ➤ Do not store outdoors.

7. COMMISSIONING

7.1 PERSONNEL REQUIREMENTS


All work on the Cobot Station must be carried out by qualified and authorized specialists.

7.2 CONNECTION/WIRING

The connection/wiring of the cobot station is not performed by Robotunits. Please follow the instructions of the cobot manufacturer.

Procedure:

- Cobot is mounted
- ⇒ Lock the lifting rollers (see picture)
- ✓ Cobot station is ready for operation.



Locking the lifting rollers

CAUTION



Hazard due to Cobot Station rolling away

Risk of injury to the lower limbs due to the Cobot Station rolling away.

- Lock the lifting rollers before switching on the cobot.

8. MAINTENANCE, SERVICING AND CLEANING

Proper maintenance of the interchangeable equipment is essential for reliable operation and a long service life.

Work to be performed by the operating personnel:

- Clean with dry or slightly damp soft cloths.
- Use a vacuum cleaner to remove larger quantities of contamination.
- Clean sensors, if necessary.
- Visual inspection for damage; if necessary, request repair from the plant maintenance department

9. DISPOSAL

The product contains valuable materials (metals, plastics, electrical assemblies) which can be recycled separately.

At the end of its service life, the product must be taken to a specialist disposal center.



SYSTEMATICALLY >>>>
>>> BETTER TOGETHER

We reserve the right to alter technical specifications at any time.
We assume no liability for typesetting and printing errors.

Austria • Germany • Switzerland • Italy • France • Spain • Czech Republic • USA • Australia

www.robotunits.com